

Solatube® 21-0 (21 in/530 mm Daylighting System) Open Ceiling Trim Ring Installation Instructions

Step 1: Slide trim ring over the tube, pinching together flanges to cover rough opening.

Step 2: Tighten trim ring around the tube with (2) bolts, washers and wing nuts provided (**Diagram A**).

Step 3: Pierce the tube at the base of trim ring with (4) screws provided (**Diagram B**).

ADDENDUM TO PARTS LIST

	Quantity
1. Open Ceiling Trim Ring	(1)
2. Screw #8 x 3/4 in	(4)
3. Bolt #10 -32	(2)
4. Washer #10	(2)
5. Wing Nut #10 -32	(2)

